



IMPORTANT SAFEGUARDS READ AND FOLLOW ALL SAFETY INSTRUCTIONS.

When using electrical equipment, basic safety precautions should always be followed including the following:

- DISCONNECT AC POWER SUPPLY BEFORE SERVICING.
- Installation and servicing of this equipment should be performed by qualified service personnel only.
- Ensure that the electrical wiring conforms to the National Electrical Code NEC® and local regulations if applicable.
- Do not mount near gas or electrical heaters.
- Equipment should be mounted in locations and at heights where it will not be readily subjected to tampering by unauthorized personnel.
- The use of accessory equipment not recommended by the manufacturer may cause an unsafe condition.
- · Any modification or use of non-original components will void the warranty and product liability.
- Do not use this equipment for other than intended use.

SAVE THESE INSTRUCTIONS!

Technical Support ■ (623) 580-8943 ■ technicalsupport@barronltg.com







Installation

- 1. Make sure the luminaire can be 0-10V dim to off and the driver has an AUX output.
- 2. Screw the sensor into the AUX receptacle and make sure the connection is tight. Ensure the rubber gasket touches the outside surface of the fixture. (Fig. 1)
- 3. Attach the lens to the sensor and turn the lens module clockwise to ensure it locks into place.
- 4. Please refer to the wiring diagram below. (Fig. 2)
- 5. Return power back to the source.
- 6. Commission the sensor via the LiteLogic App.

Wiring Diagram





NOTE: This Bluetooth device is compatible with LiteLogic lighting control system only.



How to Control Lights with a Phone?

Scan the QR Code below for APP instructions.



