

IMPORTANT SAFEGUARDS READ AND FOLLOW ALL SAFETY INSTRUCTIONS.

When using electrical equipment, basic safety precautions should always be followed including the following:

- DISCONNECT AC POWER SUPPLY BEFORE SERVICING.
- Installation and servicing of this equipment should be performed by qualified service personnel only.
- Ensure that the electrical wiring conforms to the National Electrical Code NEC® and local regulations if applicable.
- Do not mount near gas or electrical heaters.
- Equipment should be mounted in locations and at heights where it will not be readily subjected to tampering by unauthorized personnel.
- The use of accessory equipment not recommended by the manufacturer may cause an unsafe condition.
- Any modification or use of non-original components will void the warranty and product liability.
- Do not use this equipment for other than intended use.

SAVE THESE INSTRUCTIONS!

Technical Support ■ (623) 580-8943 ■ technicalsupport@barronltg.com



RHL-ACDL, RHL-ACFDL



Drop Lens Installation Instructions

- 1. Start this installation after the fixture and refractor is completely installed, secure and powered off.
- 2. Find the metal clamp and drop lens from the packaging.
- 3. Position the drop lens to the refractor bottom surface and align the mounting flanges (Fig. 1).
- 4. Expand the metal clamp (Fig. 2) and position it over both the refractor and the drop lens mounting flanges and clamp them together.
- 5. Ensure the metal clamp is fully engages the flanges and spring retainer is secure.
- 5. Check security.
- 6. Installation complete (Fig.3).





