

## SAVE THESE INSTRUCTIONS!

#### READ CAREFULLY AND FOLLOW ALL INSTRUCTIONS FOR YOUR OWN SAFETY

#### • DISCONNECT AC POWER SUPPLY BEFORE SERVICING.

- Installation and servicing of this equipment should be performed by qualified service personnel only.
- Ensure the electricity connections conform to the National Electrical Code and local regulations if applicable.
- Do not mount near gas or electrical heaters.
- Equipment should be mounted in locations and at heights where it will not readily be subjected to tampering by unauthorized personnel.
- The use of accessory equipment not recommended by the manufacturer may cause an unsafe condition. Any modification or use of non-original components will void the warranty and product liability.
- Do not use this equipment for other than intended use.



# INSTALLATION INSTRUCTIONS

- 1. Feed wire lead from 3/4" NPT knuckle into weatherproof box cover / post top fitter, whichever applies, then securely seat knuckle into box cover / post top fitter.
- 2. Electrical connections should be made inside junction box. Cap all unused leads to prevent shorting. This fixture auto adjust for voltages between 120VAC 277VAC
  - a. Connect the line fixture lead to the black supply lead.
  - b. Connect the common fixture lead to the white supply lead
  - c. Connect the ground lead form the service to the green grounding screw.

3. Use approved connectors to connect fixture leads to supply leads and make wire splices inside junction box.

### IMPORTANT

To weather-proof your outdoor installation, be sure to seal all holes in fixture housing. (Mounting, conduit, plugs, and photo controls, etc) with silicone sealant.

