

**SAVE THESE INSTRUCTIONS!**


**READ CAREFULLY AND FOLLOW ALL INSTRUCTIONS FOR YOUR OWN SAFETY**

- **DISCONNECT AC POWER SUPPLY BEFORE SERVICING.**
- Installation and servicing of this equipment should be performed by qualified service personnel only.
- Ensure the electricity connections conform to the National Electrical Code and local regulations if applicable.
- Do not mount near gas or electrical heaters.
- Equipment should be mounted in locations and at heights where it will not readily be subjected to tampering by unauthorized personnel.
- The use of accessory equipment not recommended by the manufacturer may cause an unsafe condition. Any modification or use of non-original components will void the warranty and product liability.
- Do not use this equipment for other than intended use.



**INSTALLATION INSTRUCTIONS**

1. Loosen (2) screws from mounting box to remove back plate.
2. Position mounting plate over junction box and remove desired knockouts, then secure with hardware provided by junction box.
3. Slip mounting gasket over socket adapter leads and line up mounting key slots. Remove desired conduit plug, feeding leads through hole.
4. Electrical connections should be made inside junction box. Cap all unused leads to prevent shorting. This fixture auto adjust for voltages between 120VAC - 277VAC.



- a. Connect the line fixture lead to the black supply lead.
  - b. Connect the common fixture lead to the white supply lead.
  - c. Connect the ground lead from the service to the green grounding screws.
5. Re-install mounting box to backplate


6. Install globe by twisting clockwise until tight, secure by tightening allen set screws with tool provided.

**Note:** Periodically check and remove any accumulated dirt or debris from the lens and around fixture.

**GENERAL SAFETY INSTRUCTIONS**

**WARNING:** Do not handle an energized fixture or energized any fixture with wet hands or when standing on wet or damp surface, or in water.

1. External parts of fixture develop high operating temperatures. To avoid possible injury, do not touch external parts of fixture when it is in operation.
2. Turn off power and allow fixture to cool before touching for any reason.
3. This fixture is intended to be used for general lighting in a normal open-air ambient.
4. Do not install in dead air, sheltered, buried or boxed in location. This fixture should not be installed in areas that will entrap heat. It is not intended to be used in potentially dangerous locations such as flammable or explosive atmospheres.
5. Not for use in car washes.
6. Failure to follow above safety instructions could result in fatal shock or fire hazards.



**Troubleshooting Guide**

Symptoms	Possible Cause(s)	Corrective Action
Lamp does not light	<ol style="list-style-type: none"> <li>1. No power to unit.</li> <li>2. Loose lamp connection</li> <li>3. Burned out lamp.</li> <li>4. Loose wiring</li> </ol>	<ol style="list-style-type: none"> <li>1. Check circuit protection device (circuit breaker, fuse or switch).</li> <li>2. Remove lamp, clean contacts and tighten in socket.</li> <li>3. Replace</li> <li>4. Recheck wiring connections.</li> </ol>

with power off